

INSTALLATION



3513-DM CABINET LOCK

Instructions For Lock Mode Change


1. Remove the 2 screws on the bottom.
2. Remove base plate and solenoid.
3. Turn assembly 180° and install into housing.

NOTE: Care should be taken to prevent damage to switch lever.


4. Insert the two screws.




Installation Dimensions



Install rubber pad in between the mounting surface and catch to secure catch position




Swinging Cabinet Door




Sliding Cabinet Door

Locking Pin Monitor Switch Wiring Diagram 125VAC; 1A / 30VDC; 0.5A



Cabinet Lock Dual Voltage Wiring Diagram 12VDC (200mA)



Door Monitor Switch Wiring Diagram 125VAC; 3A / 30VDC; 2A



Cabinet Lock Dual Voltage Wiring Diagram 24VDC (100mA)

